1.	Enable Alexa	servio	ce on WiFi N	VR host					
		Main Menu							
ş		8	3			0			
General Setup Re		Rec	cord Setup		ork Setup		Channel Se		
Net	work Setup		ODHCP						
	DDNS		IP Address		192, 168	3. 1.	189		
			Subnet Masl	k	255. 255	5. 255.	0		
	E-Mail		Gateway		192. 168	192. 168. 1. 1			
Wir	eless Setup		MAC Addres	9CA3-A9E4-7F24					
			Preferred D	vs	192.168	3. 1.	1. 1		
	PPPOE		Web Port		80				
Wire	less Internet		MTU		1400				
			Network Ba	ndwidth	100	Mb	Mb/s		
			Network s	ervice	3				
			Network Sta	atus 🤨	Gateway	Unrea	chable		
			Network service						
	RTSP Server		⊗Enable						
			2.0	i banan					
	Alexa		Senable ►						
	Chromecas	t	⊖Enable						

2. Download the EseeCloud APP, add device after completing the registration process.



3. Download the Amazon Alexa App, please follow the operation shown in the figure below after registering an Amazon Alexa user.







4. When your device has been added to the Alexa APP, please say to echo show: "Alexa, show me the camera one", and echo show will complete the screen projection of the device "camera one". (Tips: "camera one" means device name)

